

HermanMiller Zeph Chair



Seat Height: Lever on right side



To raise:
Take your weight off chair,
pull lever up.



To lower:
While seated and fully upright,
pull lever up.

At the proper height, your feet should rest flat on the floor.

Footrest Height: Circular support below seat

Only available on stool models.



To adjust footrest height:
Grasp the center housing of the
footrest and depress the lever.



While holding the lever, raise or
lower the footrest to desired height
and release the lever into one of the
eight lockable positions.

Seat Pad: Clips beneath the seat

Only available on some models.



To install:
Wrap the seat pad around
the edges of the seat.

Snap the clips into the slots
beneath the seat on each side.

Unibody: Clips beneath the seat

Only available on some models.



To install:
Wrap the unibody around the
edges of the back and seat.

Snap the clips into the slots
beneath the seat on each side.